

α ALPHA ANTENNA®

HD Tripod Mount Update – Version 2.0

Make sure your tripod has a black handle a brass male threaded bolt.



Assembly

- 1) Remove old hardware from your HD Tripod.
- 2) Screw the black piece onto the top of your tripods brass bolt that has a hole through the middle of it.
- 3) Insert the hex bolt up through the hole on the brass bolt in the center and under the head of your HD Tripod after removing prior hardware.
- 4) Place the washer over the bolt.
- 5) Screw the Hex Nut onto the bolt and tighten it. Feel free to hit it with a hammer drill if you have one.